



# Toshiba Satellite P205-S8811 Disk Drive Replacement

This guide will show you how to take out the disk drive and replace it with ease.

Written By: Bradley Johnson



## INTRODUCTION

If your disk drive is not reading any disks or can not open, then this guide will help you quickly replace it.

---



### TOOLS:

- [Spudger](#) (1)
  - [T8 Torx Screwdriver](#) (1)
-

## Step 1 — Battery



- Flip the laptop over so the bottom is facing upward and the battery is on top.
- Slide the tab below the battery to the left.


## Step 2



- Slide and hold the tab on the right side of the battery to the right.
- While holding the right tab, slide the battery upward and out its socket.



## Step 3 — Disk Drive





- Remove the 8mm Phillips #1 screw that holds the disk drive in place.

## Step 4



- Use a plastic opening tool to pry out the disk drive.

## Step 5



- Once the disk drive becomes loose, slowly slide it out and set it aside.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 03:43:34 PM.